Le vibromasseur Fuschia offre une double stimulation et des sensations exceptionnelles. Fait de silicone hypoallergénique, il dispose de plusieurs modes de vibration et d'intensités pour permettre une exploration sexuelle plus approfondie.

Mode d'emploi

- Avant la première utilisation, assurez-vous que la batterie est pleinement chargée.
- Appliquez un lubrifiant à base d'eau sur les zones que vous souhaitez stimuler au besoin.
- Activez la vibration en appuyant
 secondes sur le bouton (+).
 Appuyez à nouveau pour parcourir les différents modes et intensités de vibration et trouver celui qui vous convient le mieux.
- Déplacez le vibromasseur sur les zones érogènes qui vous procurent du plaisir.
- 5. Appuyez 3 secondes sur le bouton (-) pour l'éteindre.

Entretien

Nettoyez le vibromasseur avec le nettoyant Steri-clean avant et après chaque utilisation. Conservez-le dans son emballage d'origine pour prolonger sa durée de vie.

Avertissement

Ne partagez pas votre vibromasseur avec d'autres personnes, car cela peut augmenter le risque de contracter des infections sexuellement transmissibles ou autres maladies.


Garantie

Pour toute information concernant la garantie de votre produit, veuillez consulter notre site internet:

floravi.com

N'hésitez pas à nous écrire pour nous faire part de vos commentaires: info@floravi.com

Instructions de recharge



Floravi

DOUBLE VIBRATOR VIBROMASSEUR DOUBLE



User guide

Guide d'utilisation

The Fuschia vibrator offers dual stimulation and provides exceptional sensations. Made of hypoallergenic silicone, it features multiple vibration modes and intensities, allowing for deeper sexual exploration.

Instructions for use

- 1. Before first use, ensure the battery is fully charged.
- Apply a water-based lubricant to the areas you wish to stimulate, if needed.
- Activate the vibration by pressing the (+) button for 3 seconds. Press again to cycle through different vibration modes and intensities to find the one that suits you best.
- 4. Move the vibrator over the erogenous zones that bring you pleasure.
- 5. Press the (-) button for 3 seconds to turn it off.

Maintenance

Clean the vibrator with Steri-clean cleaner before and after each use. Store it in its original packaging to extend its lifespan.

Warning

Use water-based lubricant. Do not share your vibrator with others, as this may increase the risk of contracting sexually transmitted infections or other diseases.

Warranty

For more information about your product's warranty, please visit our website: **floravi.com**.

For any questions or feedback, contact us at: info@floravi.com

Charging Instructions



floravi.com f @ / floraviCanada

FUCHSIA

Double Vibrator

5 vibration modes

5 intensity levels

Easy to use

Splash resistant

Rechargeable

Internal and external stimulation

Body-safe silicone

Whisper quiet

Vibromasseur double

5 modes de vibration

5 niveaux d'intensité

Facile à utiliser

Résistant aux éclaboussures

Rechargeable

Stimulation interne et externe

Silicone hypoallergénique

Silencieux