

Avec sa silhouette affinée et son design ergonomique, le vibromasseur paume offre une stimulation externe à la fois puissante et polyvalente. Ses intensités personnalisables et ses multiples modes de vibration s'adaptent à tous vos désirs, que ce soit pour un moment en solo ou en couple.

Fonctionnement

1. Avant la première utilisation, assurez-vous que la batterie est pleinement chargée.
2. Appliquez un lubrifiant à base d'eau sur les zones que vous souhaitez stimuler au besoin.
3. Activez la vibration en appuyant sur le bouton à l'endos du bout arrondi pendant 3 secondes.
4. Naviguez les 10 différents modes de vibration en appuyant sur le même bouton.
5. Déplacez le vibromasseur sur les zones érogènes qui vous procurent du plaisir.

6. Éteignez-le en maintenant le bouton pendant 3 secondes où jusqu'à ce qu'il s'éteigne.

Entretien

Nettoyez le Vibromasseur paume avec le nettoyeur Steri-clean avant et après chaque utilisation.

Conservez-le dans un endroit frais et sec à l'abri des rayons de soleil, de la chaleur et de la poussière.

Avertissement

Pour utilisation externe seulement. Ne partagez pas votre Vibromasseur paume avec d'autres personnes, car cela peut augmenter le risque de contracter des infections sexuellement transmissibles ou autres maladies.

Garantie

Pour toute information concernant la garantie de votre produit, veuillez consulter notre site internet: floravi.com

N'hésitez pas à nous écrire pour nous faire part de vos commentaires: info@floravi.com

Floravi

PALM MASSAGER
VIBROMASSEUR PAUME



User guide
Palm Massager

Guide d'utilisation
Vibromasseur paume

The Palm massager, with its thin silhouette and ergonomic design, offers powerful and versatile external stimulation with customizable intensity settings. Its multiple vibration modes adapt to your needs for both individual or partner play.

How to use

1. Make sure it is fully charged before use.
2. Apply a water-based lubricant to the area you wish to stimulate if needed.
3. Turn on the device by pressing the button at the back of the rounded end for 3 seconds.
4. Navigate the 10 various vibration modes by pressing the button again.
5. Move the massager over your erogenous zones, focusing on areas that feel good to you.
6. Turn off the massager by pressing and holding the button for 3 seconds or until the massager stops.

Maintenance

Clean the massager before and after every use with Steri-clean.

Store the massager in a cool, dry place away from direct sunlight, heat and dust.

Warning

For external use only. Do not share your massager with others as this can increase the risk of transmitting sexually transmitted infections or other diseases.


Warranty

For all information regarding the warranty of your product, please refer to our website: floravi.com

Feel free to write us and let us know your comments: info@floravi.com

Charging Instructions

Instructions de recharge



Palm Massager

10 vibration modes

Whisper quiet

Easy to use

Splash resistant

Rechargeable

Travel size

Discreet and versatile

Vibromasseur paume

10 modes de vibration

Silencieux

Facile à utiliser

Résistant aux éclaboussures

Rechargeable

Format de voyage

Discret et versatile